



# PlayStation 3 Slim Laser lens Replacement



PlayStation 3 Slim Laser lens Replacement

Written By: ZFix

# PS3

PlayStation 3 slim

## laser lens replacement



## INTRODUCTION

Video tutorial - how to replace Laser Lens only:

[Please SUBSCRIBE to my channel ツ](#)

[video: <https://www.youtube.com/watch?v=GvL3r8N1-dc>]



---




### TOOLS:


- [Metal Spudger](#) (1)
  - [Phillips #1 Screwdriver](#) (1)
  - [Spudger](#) (1)
  - [T8 Torx Security Bit Screwdriver](#) (1)
-

## Step 1 — Blu-ray Disc Drive




 If present, remove the pieces of tape securing the cables to the body of the Blu-ray drive.

## Step 2




- Use the flat end of a spudger or your fingernail to flip up the retaining flap on the Blu-ray ribbon cable socket.

 Be sure you are prying up on the movable retaining flap, **not** the socket itself.



### Step 3



- Pull the Blu-ray ribbon cable straight up and out of its socket.

### Step 4



- Pull the Blu-ray power cable straight up to lift its connector out of the socket on the Blu-ray drive.

## Step 5





- Remove the single 9.5 mm Phillips screw securing the Blu-ray drive to the lower case.

## Step 6



- Lift the Blu-ray drive slightly by its right edge to dislodge the control board from its housing.
- Remove the Blu-ray drive from the PS3.

 After you reinstall the Blu-ray drive, be sure the control board is firmly seated in the lower case before proceeding.

 If replacing the Blu-ray drive with a new drive, swap the circuit board from your old drive into the new drive.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 03:30:37 AM.